LASCO

Cutting and drilling tool detector

WARNING

Do not work on the detector when it is powered.

Please read the wiring instructions carefully to avoid damaging the device

GENERAL DESCRIPTION

The LASCO detects long, intense and strident sounds produced by the use of a angle grinder or a drill to cut or drill a metallic material (safe, gate, ...).


INSTALLATION

The detector is installed under the ceiling like conventional security detectors.

The detector's casing is fixed to the ceiling with 2 screws (Fig. 1). The mounting holes are pre-cut in the top cover. The casing must not be drilled again.

If the mounting structure is likely to transmit vibrations. it is recommended to insulate the detector from it with a double-sided foam rubber (type 3M 9448A) with a minimum thickness of 3 mm.

The detector is connected to the security control panel with a 3-pair flexible alarm cable. Depending on the circumstances, the cable can be routed either through the ceiling or through the side of the detector. The tamper switch detects the opening of the detector's casing.



WIRING INSTRUCTIONS

Power voltage: from 12 to 24 Vcc Connection direction is important! (see Fig. 2).

The position of the alarm contact activation mode jumper corresponds to Normally Closed (NC) operation mode. Move the jumper to operate in Normally Open (NO) mode.

Make sure that the tamper bump on the top cover faces the tamper switch when the casing is closed.





Fig. 2 : Circuit board

LED OPERATIONS

When the detector is powered on:


LED L1 (red) is always on. LED L2 (yellow) flashes every second: this means that the detector is operational. It flashes faster when one is connected to the detector's Wi-Fi network.

LED L3 (yellow) lights up for 20s at start-up and then goes out when the detector is operational. In the event of an alarm, it lights up for the duration of the lock activation time (see CONFIGURATION SITE), then goes out.



PLACEMENT OF THE LASCO

Install the LASCO in the room to be protected, near the entrances or objects likely to be attacked. Generally, one LASCO in the center of a room of 40 m² is sufficient, but it is recommended to install several detectors in rooms with numerous corners.



CONNECTION TO DETECTOR

The detector is configured on an embedded website. Connect to the Sensivic network:

SSID : Sensivic-XXXX (XXXX : serial number)

Password : Qjafccnuas In a web browser page, type the IP address of the detector:

192.168.1.10

To indicate that you are connected to the detector's network, the detector's central LED flashes

On smartphones, it is sometimes necessary to disable mobile data to get access to the configuration site.

CONFIGURATION SITE

DETECTION

Detector choice Choose the type of detector you want to use. Then click on «Activate».

WARNING

The detector will reboot to take this setting into account. You will temporarily lose the connection to the detector's Wi-Fi network.

Detection settings

WARNING After changing a setting, click «Save» for the setting to take effect.

Vigilance Level

This parameter determines the sensitivity of the detector. By default, the detector is set to a medium vigilance level (**High vigilance**. ■ : Low vigilance.

intended for use in operations.

RECOMMENDATION

Listening range

radius (m)

1.0

2.0

40

8.0

Lock activation time

Relav activation time

the alarm control panel.

CONNECTION

LASCO.

seconds).

Duration during which the detection

is interrupted after an alarm

(between 4s and 120s). By default,

the locking time is 10s for the

Duration of activation of the dry

contact during an alarm (between

500ms and 5000ms). By default, the

relay activation time is 1500ms (1.5

Test alarm

It is possible to generate a false

alarm by clicking on the «Send a

test alarm» button to test whether

the detector's alarms are notified to

Detector's name

Choose a name that allows you to

identify the detector when you

connect to it. This name is not

related to the detector's Wi-Fi

Wi-Fi password

WARNING

The "Tests and Demos" profile is unusually sensitive and is not USS SENSIVIC S.A.S. Le Lab'O, 1 avenue du Champ de Mars, 45074 ORLÉANS CEDEX 2 - France SIRET 81532197100021 N° TVA FR48815321971 Recommended Code NAF 4741Z vigilance level

Internet Connection

SENSIVIC ®

Real-time Smart Audio Detection

Tel. +33 (0)2 38 69 82 96

contact@sensivic.com

CE

To connect the detector to the Internet enter the name and password of an Internet access point here, click on «Save Connection Options», then reboot the detector

If the detector is connected, the message «You are connected to the network!» appears on the left side of the window. Enable the «Automatic connection» switch so that the detector automatically reconnects to the access point after a reboot.

MONITORING

Sound characteristics Sound pressure in milli-Pascal (mPa) and sound level in decibels (dB) measured by the detector.

Operating data

Current detector settings and time since last power up (hours:minutes:seconds).

Notified event counter

Counter of events notified (alarms) since the last powering up of the detector. To reset the counter to 0, click on the «Reset to 0» button.

UPDATE

This page allows you to update the detector.

Update

Click on «Browse...» and select the bin file of the detector software. supplied by SENSIVIC, then click on «Update firmware».

LASCO

Cutting and drilling tool detector

Installation and configuration manual



Previous version

If you wish to revert to the previous version of the detector software after an update, click «Check the version» and then, if a previous version of the software is found. click on the button «Revert to Previous Version»

REBOOT THE DETECTOR

It is possible to reboot the detector by clicking on the button «Reboot the detector».

TECHNICAL SPECIFICATIONS

Power

Voltage: from 12 to 24 Vcc Power consumption: 1 W

Environment

Temperature: from -40°C to +85°C Humidity: up to 95% without condensation

Dimensions

80 mm x 65 mm x 40 mm Casing: white ABS IP40 Weight: 100g

These data are provided for information only. They are not contractual. USS SENSIVIC reserves the right to make any improvements that it deems useful to its products.

Change the connection password of the detector's Wi-Fi network here, click on «Set password», then reboot the detector.

network name.

To reset the password to default (Qjafccnuas), you have to open the detector's casing and press the **boot** button for at least 5 seconds with a thin rod (Fig. 2).

Fig. 1 : Mounting of the casing top cover

faster. NOTE